USER MANUAL
USB Server

Model No.: USB-SVR100 (1 USB port)

Model No.: USB-SVR200 (2 USB ports)

Password

Password is used to protect your configuration from unauthorized access. The password consists of a maximum of 36 characters and can be null (blank).

I. Features

- Supports USB 2.0/1.1 compliant devices
- Supports Universal Serial Bus over IP (Device Sharing Over Internet) and an USB Device Management
- Supports Windows 10/8.1/8/7/Vista/XP, Windows Server 2016/2012/2008/2003, Mac OS 10.x, Linux, Android 4.x, Chrome OS
- Supports 10 / 100 Mbps Ethernet, Auto MDI/MDI-X
- Use USB devices as if connected to the server (virtually) anywhere on the LAN or Internet
- Software supports Windows 32-bit and 64-bit

II. Package Content

Before you start, please check if your package contains the following:

- One USB Server
- Quick Installation Guide
- CD-ROM (User Manual included)
- DC 5V PSU

III. Hardware Installation

USB-SVR100/SVR200

USB-SVR100 Application Diagram

IV. Installation

1. Locate the USB-SVR100 / USB-SVR200 from the USB Server Utility. Or,

Please select the USB Server you want to configure from the installation screen.

Click on the Refresh button if the desired USB Server does not show in the list.

Click on the Exit button to close the installation screen.

Running the program

After the installation is complete, please follow the path: All Programs -> USB Server -> USB Server Utility to run the program.

The search dialog box will display all available USB Servers.

System Firewall

If you have enabled the system firewall, your Windows XP will prompt you the Firewall Security Alert dialog box. Please select Unblock this program and click OK to allow the USB Server to function properly.

Windows XP Firewall Security Alert

Please select Unblock, then OK, to proceed.

Windows Firewall Exceptions

If you're running Windows Vista, please select Unblock.

Windows Firewall Security Alert

Please select Unblock, then OK, to proceed.

2. Select the USB Server you want to configure from the list and click on "Select".

Basic Configuration

Click on the Basic Configuration button to go through the Wizard, you can configure the following:

The Wizard will automatically detect the USB Server's current IP address and Subnet Mask settings. If you want to change the IP address, please enter the new IP address and Subnet Mask.

Click Next to continue.

Please enter the Server Name and Description for the USB Server.

Click Next to continue.

Please enter the Date and Time for the USB Server.

Click Next to continue.

Please enter the Password for the USB Server.

Click Next to continue.

Please click the Restart button to restart the USB Server.

Status of USB Ports and Devices

The lower half side of the Main Window of the USB Server Utility shows the status of the USB ports and devices connected to the USB Server. The Port Status tab shows the USB port number, the device connected to the port, and the port status.

Disconnect - To free a port.

Connect - To connect to a port.

Disconnect All - To free all ports.

Refresh - To refresh the port status.

Rescan - To rescan the USB Server.

Rescan and Reconnect All - To rescan and reconnect to all USB devices.

Reset - To reset the USB port.

Reset and Reconnect All - To reset and reconnect to all USB devices.

Occupied - To free a port.

Occupied and Reconnect All - To free all ports and reconnect to all USB devices.

Unoccupied - To occupy a port.

Unoccupied and Reconnect All - To occupy all ports and reconnect to all USB devices.

Advanced Configuration

Click on the Advanced Configuration button to go to the Advanced Configuration Utility.

Click on the Network Configuration button to configure the network settings.

Click on the Password Configuration button to configure the password settings.

Click on the Date and Time Configuration button to configure the date and time settings.

Click on the Restart Server button to restart the USB Server.

Network Configuration

The Network Configuration allows you to configure the network settings for the USB Server.

Obtain an IP address automatically - Select this option if you want to obtain an IP address automatically from a DHCP server.

Specify an IP address - Select this option if you want to specify the IP address manually.

IP Address - Specify the IP address here.

Subnet Mask - Specify the Subnet Mask here.

Gateway - Specify the Gateway here.

Primary DNS - Specify the primary DNS here.

Secondary DNS - Specify the secondary DNS here.

Change Password

Click on the Change Password button to configure the password settings.

Password Change

Check the Password Change box if you want to change the password.

Old Password - Enter the old password here.

New Password - Enter the new password here.

Confirm Password - Enter the new password again here.

Click OK to save the changes.

Date and Time Configuration

The Date and Time Configuration allows you to configure the date and time settings for the USB Server.

Manual Date and Time Settings - Select this option if you want to configure the date and time manually.

Synchronize with NTP Server - Select this option if you want to synchronize the date and time with an NTP server.

Time Zone - Select the time zone for your location.

Daylight Saving - Select this option if you want to enable daylight saving.

Click OK to save the changes.

Restart Server

Click on the Restart Server button to restart the USB Server.

Click OK to restart the USB Server.

Configuration with Web Browser

The USB Server provides a web-based configuration utility. This is the recommended method for configuring the USB Server. It allows you to configure the USB Server from any computer on the network that can run a web browser.

Configuration with Web-based Air

The USB Server provides a web-based configuration utility. This is the recommended method for configuring the USB Server. It allows you to configure the USB Server from any computer on the network that can run a web browser.

Windows Security Alert dialog box will pop up. Click on Allow access.

The Configuration Utility will open in the web browser. The default username is "admin" and the default password is "admin". Click on Login to continue.

The Configuration Utility has the same functions as the Windows-based Configuration Utility described above.

Network Configuration

Configuration with the Utility

The USB Server provides a utility for configuration through USB Ethernet. By using this utility, you can configure the network settings, password settings, date and time settings, and restart the server.

USB Port - Shows the USB port number.

Device Name - Shows the name of the device connected to the USB port.

Status - Shows the status of the USB port.

Connect - Connect to the device connected to the USB port.

Disconnect - Disconnect the device connected to the USB port.

Refresh - Refresh the USB port status.

Rescan - Rescan the USB Server.

Reset - Reset the USB port.

Configuration - Configure the USB Server.

Change Password

Click on the Change Password button to configure the password settings.

Password Change

Check the Password Change box if you want to change the password.

Old Password - Enter the old password here.

New Password - Enter the new password here.

Confirm Password - Enter the new password again here.

Click OK to save the changes.

Network Configuration

The Network Configuration allows you to configure the network settings for the USB Server.

Obtain an IP address automatically - Select this option if you want to obtain an IP address automatically from a DHCP server.

Specify an IP address - Select this option if you want to specify the IP address manually.

IP Address - Specify the IP address here.

Subnet Mask - Specify the Subnet Mask here.

Gateway - Specify the Gateway here.

Primary DNS - Specify the primary DNS here.

Secondary DNS - Specify the secondary DNS here.

Click OK to save the changes.

Restart Server

The buttons have the same functions as the buttons in the Windows-based Configuration Utility described above.

Password Configuration

The Password Configuration allows you to configure the password settings for the USB Server.

Old Password - Enter the old password here.

New Password - Enter the new password here.

Confirm Password - Enter the new password again here.

Click OK to save the changes.

Date and Time Configuration

The Date and Time Configuration allows you to configure the date and time settings for the USB Server.

Manual Date and Time Settings - Select this option if you want to configure the date and time manually.

Synchronize with NTP Server - Select this option if you want to synchronize the date and time with an NTP server.

Time Zone - Select the time zone for your location.

Daylight Saving - Select this option if you want to enable daylight saving.

Click OK to save the changes.

Restart Server

Click on the Restart Server button to restart the USB Server.

Click OK to restart the USB Server.

Create a Shortcut on Your Desktop

The Control Center provides a convenient way to start your USB devices. Instead of starting the USB Server Utility and then selecting the USB device you want to use, you can select a USB device from the Control Center and the USB Server Utility will automatically start and select the USB device you want to use. The Control Center is a floating window that can be placed anywhere on your desktop. It displays the USB devices that are connected to the USB Server. You can connect to a USB device by clicking on the device's name. If you are using the device, you can release it by clicking on the device's name again. You can also release the device by right clicking on the Control Center and selecting the device you want to release.

NOTE: The Control Center will automatically release a USB device if you have not used it for over 10 minutes. If you have a USB device that you only use occasionally, you may want to disable the Control Center for that device. Just release the device, then right click on the Control Center and select the device you want to disable.

Create a Shortcut on Your Desktop

The Control Center provides a convenient way to start your USB devices. Instead of starting the USB Server Utility and then selecting the USB device you want to use, you can select a USB device from the Control Center and the USB Server Utility will automatically start and select the USB device you want to use. The Control Center is a floating window that can be placed anywhere on your desktop. It displays the USB devices that are connected to the USB Server. You can connect to a USB device by clicking on the device's name. If you are using the device, you can release it by clicking on the device's name again. You can also release the device by right clicking on the Control Center and selecting the device you want to release.

NOTE: The Control Center will automatically release a USB device if you have not used it for over 10 minutes. If you have a USB device that you only use occasionally, you may want to disable the Control Center for that device. Just release the device, then right click on the Control Center and select the device you want to disable.

Create a Shortcut on Your Desktop

The Control Center provides a convenient way to start your USB devices. Instead of starting the USB Server Utility and then selecting the USB device you want to use, you can select a USB device from the Control Center and the USB Server Utility will automatically start and select the USB device you want to use. The Control Center is a floating window that can be placed anywhere on your desktop. It displays the USB devices that are connected to the USB Server. You can connect to a USB device by clicking on the device's name. If you are using the device, you can release it by clicking on the device's name again. You can also release the device by right clicking on the Control Center and selecting the device you want to release.

NOTE: The Control Center will automatically release a USB device if you have not used it for over 10 minutes. If you have a USB device that you only use occasionally, you may want to disable the Control Center for that device. Just release the device, then right click on the Control Center and select the device you want to disable.

LED Panel - Shows the device's information, such as the occupied IP address, connection time, and MAC address. If no device is connected to the USB port, this field will be blank.

Refresh - Refresh the device's information.

Auto Connect to Printer (With Windows Operating System) - Select this option if you want to automatically connect to the USB printer when the USB Server is powered on.

Auto Disconnect - Select this option to disable the USB port after a period of inactivity. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.



When you print the document, you will see the USB device's name and port number.



When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Auto Disconnect Printer (With Windows Operating System)

Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on.

NOTE: This function might not work with the drivers of some printers.

Auto Disconnect Printer (With Windows Operating System) - Select this option if you want to automatically disconnect the USB printer when the USB Server is powered on. Enter the amount of time (in minutes) that the USB port will be inactive before it is disabled. Select the USB port that you want to disconnect from the drop-down menu. Click Add to add the USB port to the list. Click Remove to remove the USB port from the list. Click Clear to clear the entire list.

Device Property - Click this button to configure the USB device. If the device is a storage device, you can configure the following:

Write Protect - Prevents the device from being written to.

Encryption - Encrypts the data written to the device. You can choose between 128-bit and 256-bit encryption. Enter a password to encrypt the device. The password will be required for the user data.

Port Property - Click this button to configure the USB port. You can configure the following:

Enable Bi-directional Communication - Select this option if your device supports bi-directional communication between the host and device.

Enable USB Interrupt In Transfer - Select this option if your device supports interrupt in transfer.

Enable Isochronous Transfer - Select this option if your device supports isochronous transfer.

Enable Power Saving - Select this option to enable power saving for the USB port.

Application Starts

The warning sign will then be printed out automatically. Normally, simply by the name of the USB device.

When you print the document, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When the USB device is connected to the USB port, you will see the USB device's name and port number.

When you see the USB device's name and port number, you can start printing.

Disclaimer

All the information in this document is subject to change without prior notice. The manufacturer makes no representations or any warranties regarding the contents of this document. No part of this publication may be reproduced or transmitted in any form by any means without the prior written permission of the manufacturer. All brand names and product names used in this document are trademarks or registered trademarks of their respective holders.