

### UMH-10 Compatible Models

No.	Models	Remarks
1	Roland Aerophone AE-10	
2	Roland Aerophone AE-05	
3	Roland Aerophone AE-30	The AE-30's USB driver needs to be set to "GENERIC", then reboot
4	Roland FP-90	
5	Roland FP-80	
6	Roland FP-30	
7	Roland MC-707	
8	Roland D-05	
9	Roland XPS-10	
10	Roland RD-88	The RD-88's USB driver needs to be set to "GENERIC", then reboot
11	Arturia Keylab Series	
12	Arturia Beatstep Series	
13	Arturia Keystep Series	
14	Arturia Minilab	
15	Novation Launch Control XL	
16	Novation Launchkey Series	Compatible with this model after November 17, 2020
17	Novation Launchpad X	
18	KORG MICROKEY2 Series	
19	KORG MICROKEY Air Series	
20	KORG NTS-1	
21	KORG Volcas	
22	KORG electribe	
23	KORG nano-range	
24	KORG nanoKONTROL2	
25	M-Audio Keystation Series	Compatible with this model after January 1, 2021
26	M-Audio Oxygen Series	
27	Casio CT-X3100	
28	Casio CT-X5100	
29	Casio WK-1200	
30	Casio PX-150	
31	Casio PX-160	
32	Casio PX860	
33	Casio PX-S1000	
34	Casio PX-S3000	
35	Casio CDP-S100	
36	Casio AP470	
37	Casio Privia M560	
38	AKAI EWI USB Wind Controller	
39	AKAI EWI5000	
40	AKAI MPK MINI Series	Compatible with this model after February 1, 2021
41	AKAI MPD218	
42	AKAI LPD8	
43	AKAI APC40	
44	BOSS GT-1 Guitar Effect	Note: BOSS GT-1 uses MIDI SysEx communication, not MIDI CC or MIDI PC. USB MIDI HOST only communicates MIDI and does not modify MIDI content.
45	WORLD E PANDA Series	
46	YAMAHA CVP605	
47	YAMAHA CLP-S406	

48	YAMAHA CLP-675	
49	YAMAHA CLP-545	
50	YAMAHA CLP-635	
51	YAMAHA CLP-685	
52	YAMAHA CLP-735	
53	YAMAHA P-115	
54	YAMAHA P-121	
55	YAMAHA P-125	
56	YAMAHA P-128	
57	YAMAHA YDP-144	
58	YAMAHA Gear	
59	YAMAHA PSS-A50	
60	YAMAHA AvantGrand N1X	
61	YAMAHA DGX-230	
62	ZOOM MS Series	
63	ZOOM ARQ AR-96	
64	Alesis Q25	
65	Alesis Vortex Wireless 2	
66	NUX MG-30	
67	LINE6 HX EFFECTS	
68	Evolution MK-361	
69	Key Black C49	
70	ION Discover Keyboard USB	
71	Bora Piano	
72	MidiPlus Piano	
73	Electronic Drum EDS-908	
74	ASM Hydrasynth	
75	Prophet-5 Rev 4	
76	behringer MODEL D	
77	behringer UMX610	
78	behringer Moukey MEP-110	
79	Teenage Engineering OP-1	
80	Gakken NSX-39	
81	Sensel Morph	
82	iCON iControls	
83	Fishman Tripleplay	
84	Pioneer DDJ-400	
85	Nektar IMPACT LX MINI	
	...	

#### Incompatible Models

No.	Models	Reason
1	Yamaha DTX 502	Incompatible USB version
2	ATV aD5 Electronic Drums aD5	Incompatible USB version
3	KORG MICROKEY1	

**Note1: The above are only some known models.**

**Note2: In addition, when your USB MIDI device is connected to the computer, and there is no need to install an additional USB driver, so UMH-10 is compatible.**

**If you need the computer to install a specific USB driver before you can use your midi device, please use UMH-21.**

**UMH-21 supports firmware upgrades (like installing a USB driver).**