

A

B

C







D

A

B

C

D

78mm	78mm	78mm	78mm	78mm	78mm	78mm	78mm	78mm																																																		
<div><p>BS-167 使用说明书</p><p>深圳柏克数码科技有限公司 SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD</p></div>	<div><p><b>说明书</b></p><p>尊敬的客户:</p><p>感谢您使用柏克自主研发的蓝牙音响,为了让您轻松体验产品,我们配备了内容详尽的使用说明,您从中可以获得有关产品的介绍,使用方法等方面的知识,在您使用本机前请先行阅读说明资料!</p><p><b>一、外观功能</b></p><p>① 电源键/音量旋钮 ② 充电口 ③ 充电指示灯 ④ AUX音频输入口</p></div>	<div><p><b>二、使用说明</b></p><table><tr><th colspan="2">功能键简要说明</th></tr><tr><td>Ⓢ</td><td>电源键+音量旋钮</td></tr><tr><td>AUX</td><td>音频输入接口</td></tr><tr><td>USB</td><td>microUSB充电接口</td></tr></table><p>蓝牙TWS无线立体声,无连接10分钟系统自动关机。</p><p><b>1. 蓝牙连接</b></p><p>(1)、电源键/音量旋钮 长按“Ⓢ”开机,开机后长按“Ⓢ”关机,蓝牙播放与AUX播放时,顺时针旋转为“音量增加”,定时针旋转为“音量减小”。</p><p>(2)、蓝牙模式 进入蓝牙模式需LED灯快闪,配对成功后,蓝牙信号灯慢闪,此蓝牙设备连接后,显示BS-167(蓝牙名称)如要连接新的设备请先断开已配对的设备,然后按上图中蓝牙模式的设置。</p><p>(3)、蓝牙播放 蓝牙播放成功短按“Ⓢ”键可以播放/暂停音乐,播放时短按为暂停,再按一下重新播放。</p><p>(4)、蓝牙TWS无线立体声播放 长按两个音响“Ⓢ”键开机后,短按其中1个的“Ⓢ”键,会听到进入配对模式的提示音,约10S后会配对成功,待配对成功提示音,然后再用手机搜索蓝牙,进行蓝牙连接。</p></div>	功能键简要说明		Ⓢ	电源键+音量旋钮	AUX	音频输入接口	USB	microUSB充电接口	<div><p>(5)、免提通话 电话接听:蓝牙连接后如手机来电,电话自动连接,短按“Ⓢ”键接听,连续短按两次“Ⓢ”键挂断电话,连续中短按“Ⓢ”结束通话,挂断电话后连续短按两次“Ⓢ”键重拨电话,连续通话结束后自动恢复蓝牙音乐功能。</p><p><b>2. AUX音频输入</b> 插入3.5mm标准音频线,机器自动检测到AUX播放模式播放。</p><p><b>3. 充电</b> 插入MicroUSB进行充电,充电时充电LED灯亮,满电后灯灭。</p><p><b>三、产品参数</b></p><table><tr><td>蓝牙方案:</td><td>JL V5.0</td></tr><tr><td>接收距离:</td><td>10M</td></tr><tr><td>功率:</td><td>5W X 2</td></tr><tr><td>阻抗:</td><td>4Ω</td></tr><tr><td>扬声器尺寸:</td><td>Φ50mm</td></tr><tr><td>扬声器:</td><td>2个</td></tr><tr><td>频率响应:</td><td>80Hz - 20KHz</td></tr><tr><td>信噪比:</td><td>80dB</td></tr><tr><td>连接方式:</td><td>Bluetooth ,AUX,TWS</td></tr></table></div>	蓝牙方案:	JL V5.0	接收距离:	10M	功率:	5W X 2	阻抗:	4Ω	扬声器尺寸:	Φ50mm	扬声器:	2个	频率响应:	80Hz - 20KHz	信噪比:	80dB	连接方式:	Bluetooth ,AUX,TWS	<div><p><b>四、注意事项</b></p><p>1.避免放置潮湿地方 2.定期定时充电 3.勿用硬物摩擦音响 4.使用本厂配件充电 5.原相湿布擦拭</p><p><b>五、包装清单</b></p><p>1.BS-167音响.....2个 2.音频连接线.....2条 3.充电线.....2条 4.使用说明书.....1份</p></div>	<div><p><b>六、常见问题解决方法</b></p><table><tr><th>问题</th><th>现象</th><th>解决方法</th></tr><tr><td>多次连接配对不成功</td><td></td><td>1. 检查音响是否处于搜索状态,或重新开机, 2. 周边蓝牙设备太多,造成搜索困难,关闭其他蓝牙设备。</td></tr><tr><td>声音小或失真</td><td></td><td>1. 检测蓝牙设备音量,调节其音量至合适位置, 2. 电池电压低请充电。</td></tr><tr><td>音乐出现断音</td><td></td><td>是否超出音响有效连接距离,或音响与蓝牙设备有障碍物。</td></tr><tr><td>蓝牙状态指示灯不亮</td><td></td><td>重新开机</td></tr></table></div>	问题	现象	解决方法	多次连接配对不成功		1. 检查音响是否处于搜索状态,或重新开机, 2. 周边蓝牙设备太多,造成搜索困难,关闭其他蓝牙设备。	声音小或失真		1. 检测蓝牙设备音量,调节其音量至合适位置, 2. 电池电压低请充电。	音乐出现断音		是否超出音响有效连接距离,或音响与蓝牙设备有障碍物。	蓝牙状态指示灯不亮		重新开机	<div><p><b>七、保修说明</b></p><p><b>1.保修条例:</b> 本产品有效保修期为自出售之日起12个月内,在保修期间内正常使用和维护情况下,非人为损坏,机器本机硬件材料及功能出现问题,无法正常使用,本公司将提供免费维修服务。</p><p><b>2.有信保障:</b> (1).超出保修期; (2).不能同时出示购买凭证和保修卡。 (3).错误使用(如超压充电)或擅自拆卸改装。 (4).运输、跌落或自然灾害造成故障及损坏。</p><p><b>3.保修保留:</b> 柏克保留可变更维修方式权利。如果柏克产品不能在所有国家进行维修,您可能需要承担运费和手续费。如果您在非原购国寻求维修,您须遵守所有适用的进出口法律法规,并负责所有关税、增值税及其他相关税项和收费。</p></div>	<div><p><b>产品保修卡</b></p><table><tr><td>产品型号: _____</td><td>顾客姓名: _____</td></tr><tr><td>制造编号: _____</td><td>顾客地址: _____</td></tr><tr><td>购买日期: _____</td><td>顾客电话: _____</td></tr><tr><td>购买商店: _____</td><td>E-MAIL: _____</td></tr><tr><td>商店电话: _____</td><td>邮 编: _____</td></tr></table><p>请务必认真填写好以上各项资料</p><div></div><p><b>深圳柏克数码科技有限公司</b> 地址: 深圳市宝安区福海街道塘尾富华工业城7栋 电话: +86-755-2778 2323 传真: +86-755-2778 2900 免费热线: 400-0099-806 邮箱: admin@bokecbf.com 官网: www.bokecbf.com</p></div>	产品型号: _____	顾客姓名: _____	制造编号: _____	顾客地址: _____	购买日期: _____	顾客电话: _____	购买商店: _____	E-MAIL: _____	商店电话: _____	邮 编: _____
功能键简要说明																																																										
Ⓢ	电源键+音量旋钮																																																									
AUX	音频输入接口																																																									
USB	microUSB充电接口																																																									
蓝牙方案:	JL V5.0																																																									
接收距离:	10M																																																									
功率:	5W X 2																																																									
阻抗:	4Ω																																																									
扬声器尺寸:	Φ50mm																																																									
扬声器:	2个																																																									
频率响应:	80Hz - 20KHz																																																									
信噪比:	80dB																																																									
连接方式:	Bluetooth ,AUX,TWS																																																									
问题	现象	解决方法																																																								
多次连接配对不成功		1. 检查音响是否处于搜索状态,或重新开机, 2. 周边蓝牙设备太多,造成搜索困难,关闭其他蓝牙设备。																																																								
声音小或失真		1. 检测蓝牙设备音量,调节其音量至合适位置, 2. 电池电压低请充电。																																																								
音乐出现断音		是否超出音响有效连接距离,或音响与蓝牙设备有障碍物。																																																								
蓝牙状态指示灯不亮		重新开机																																																								
产品型号: _____	顾客姓名: _____																																																									
制造编号: _____	顾客地址: _____																																																									
购买日期: _____	顾客电话: _____																																																									
购买商店: _____	E-MAIL: _____																																																									
商店电话: _____	邮 编: _____																																																									
78mm	78mm	78mm	78mm	78mm	78mm	78mm	78mm	78mm																																																		
<div><p>BS-167 USER MANUAL</p><p>SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD</p></div>	<div><p>Please read the instruction manual carefully before using the product.</p><p><b>Key function:</b></p><p>① Power and volume control button ② Charge port ③ LED indicator ④ 3.5mm audio input</p></div>	<div><p><b>Product Specification:</b></p><p>Bluetooth: JL 5.0 Power output: 5Wx2 Function: Line in,Bluetooth,Microphone Receive distance: ≤10M Impedance: 4Ω Product size: 65.5x58.8x97.5mm FrequencyResponse: 80Hz~20KHz S/N:80dB Build in 1000mAh batteryx2 Driver Size: Φ50mm</p><p>Turn on/off:Long press Ⓢ button Play/Pause/Hands free:Shortly press Ⓢ button</p></div>	<div><p><b>Bluetooth mode &amp; Hands-free mode:</b></p><p><b>Please noted this speaker can be used as a set or use separately.</b></p><p><b>When connecting 1pcs speaker:</b></p><p><b>Step 1:</b>Press Ⓢ for 3s to turn on the unit, the LED will be fast flash in blue, that means the product is waiting for pairing. <b>Step 2:</b>Turn on the Bluetooth on your device and searching for BS-167, and connect to it once you found (when successfully connect it, the LED will be in solid blue). <b>Step 3:</b>Playing music in your device.</p></div>	<div><p>When there is Bluetooth connection,you can use the speaker to answer your call. Press Ⓢ shortly to pick up any incoming call; Press and hold Ⓢ for 2s to reject any incoming call.</p><p><b>When connecting 2pcs speakers together to enjoy stereo sound:</b></p><p><b>Step 1:</b>Press Ⓢ on each speaker for 3s to turn on the unit,the LED on each speaker will be fast flash in blue, that means the product is waiting for pairing. Normally the 2 speakers will connect each other in about 3s automatically.(when 2 speakers successfully connect each other,the LED on 2 speakers will be in solid blue);If the 2 speakers</p></div>	<div><p>did not connect each other,shortly press Ⓢ on one of speaker and then they will connect each other. <b>Step 2:</b>Turn on the Bluetooth on your device and searching for BS-167, and connect to it once you found. <b>Step 3:</b>Playing music in your device. When there is Bluetooth connection,you can use the speaker to answer your call. Press Ⓢ shortly on one of speaker to pick up any incoming call ( Please noted that in this case you can only hear and talk to one speaker that can hear calling voice, there is no any voice on the other speaker) or press and hold Ⓢ for 2s to reject any incoming call.</p></div>	<div><p><b>Aux in mode:</b></p><p>Using the 3.5mm audio cable offered with one end to the product and one end to your music device, and then playing the music.</p><p><b>Charging mode:</b></p><p>Make sure 2pcs speakers are combined as one when charging. Using the USB charging cable offered with one end to one of the speaker Micro USB charge port and one end to any PC USB ports or AC Adaptor. You can also chose to charge the speaker separately by using the USB charging cable offered with one end to the speaker Micro USB Port and one end to any PC USB ports or AC Adaptor.</p></div>	<div><p><b>Charging mode:</b></p><p>Install in accordance with the manufacturer's instructions. Place the speaker in a stable location so they will not fall causing damage to the speaker or cause any bodily harm. Please ensure reasonable space around the speakers for proper ventilation. Do not install near any heat sources such as radiators,heat registers,stoves,or other apparatus that produce heat. Do not place near any form of open flame source, such as lighted candles on the apparatus. To reduce the risk of fire or electronic shock, do not expose this apparatus to rain or moisture.</p></div>	<div><p><b>Product Warranty Card</b></p><table><tr><td>Model No: _____</td><td>Customer name: _____</td></tr><tr><td>Produce No: _____</td><td>Customer address: _____</td></tr><tr><td>Purchase date: _____</td><td>Customer telephone: _____</td></tr><tr><td>Purchase shop: _____</td><td>E-MAIL: _____</td></tr><tr><td>Shop Telephone: _____</td><td>Mail code: _____</td></tr></table><p>Please fill in all the information needed carefully</p></div>	Model No: _____	Customer name: _____	Produce No: _____	Customer address: _____	Purchase date: _____	Customer telephone: _____	Purchase shop: _____	E-MAIL: _____	Shop Telephone: _____	Mail code: _____																																								
Model No: _____	Customer name: _____																																																									
Produce No: _____	Customer address: _____																																																									
Purchase date: _____	Customer telephone: _____																																																									
Purchase shop: _____	E-MAIL: _____																																																									
Shop Telephone: _____	Mail code: _____																																																									

1.材质:  
A. 80g道林纸

\*2.工艺:  
A. 80g道林纸双面单色, 正常印刷

\*3.制做工艺要求:  
A. 折叠方式:风琴折  
B. 按照文件尺寸做, 制作精致, 印刷清晰不掉色, 裁切整齐无残缺, 表面无墨点, 污点等  
C. 公差:±0.1mm

4.符合ROHS最新环保要求  
带"\*"号为QC必检项

				<div><div></div><div>深圳柏克数码科技有限公司</div><div>SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD</div></div>								
适用性		仅适用于BS-167产品包装		产品型号		BS-167		零件料号				
				零件名称		产品说明书		图纸编号				
				电脑存档								
				绘图	李兴华 2019-08-01			投影方向				
				审核				单位	mm	比例		
NO	变更内容		变更者	日期	核准				页数	1/1	版本	A/0

1

2

3

4

5

6