DOREMiDi

Update on January 5, 2022

UTB-21 Compatible Models		
No.	**Models**	**Remarks**
1	Roland FP-90	
2	Roland FP-80	
3	Roland FP-30	
4	Roland MC-707	
5	Roland D-05	
6	Roland XPS-10	
7	Arturia Keylab Series	
8	Arturia Beatstep Series	
9	Arturia Keystep Series	
10	Arturia Minilab	
11	Novation Launch Control XL	
12	Novation Launchkey Series	Compatible with this model after November 17, 2020
13	KORG MICROKEY2 Series	
14	KORG MICROKEY Air Series	
15	KORG NTS-1	
16	KORG Volcas	
17	KORG electribe	
18	KORG nano-range	
19	M-Audio Keystation Series	Compatible with this model after January 1, 2021
20	M-Audio Oxygen Series	Compatible with this model after January 1, 2021
21	Casio CT-X3100	
22	Casio CT-X5100	
23	Casio WK-1200	
24	Casio PX-160	
25	Casio PX860	
26	Casio PX-S1000	
27	Casio PX-S3000	
28	Casio CDP-S100	
29	Casio AP470	
30	Casio Privia M560	
31	Casio CDPS-100	
32	AKAI MPK MINI Series	Compatible with this model after February 1, 2021
33	AKAI MPD218	
34	AKAI LPD8	
35	BOSS GT-1 Guitar Effect	Compatible with this model after February 1, 2021
36	WORLDE PANDA Series	
37	YAMAHA CVP605	
38	YAMAHA CLP-S406	
39	YAMAHA CLP-675	
40	YAMAHA CLP-545	
41	YAMAHA CLP-635	
42	YAMAHA CLP-685	
43	YAMAHA CLP-735	
44	YAMAHA P-115	
45	YAMAHA P-121	

46	YAMAHA P-125	
47	YAMAHA P-128	
48	YAMAHA YDP-144	
49	YAMAHA Gear	
50	YAMAHA PSS-A50	
51	YAMAHA AvantGrand N1X	
52	ZOOM MS Series	
53	ZOOM ARQ AR-96	
54	Alesis Q25	
55	NUX MG-30	
56	Evolution MK-361	
57	Key Black C49	
58	ION Discover Keyboard USB	
59	Bora Piano	
60	MidiPlus Piano	
61	Electronic Drum EDS-908	
62	ASM Hydrasynth	
63	Prophet-5 Rev 4	
64	behringer MODEL D	
65	behringer UMX610	
66	Teenage Engineering OP-1	
67	Gakken NSX-39	
68	Sensel Morph	
	…	

Note: the above are only some known models.

Incompatible Models		
No.	**Models**	**Reason**
1	AKAI EWI5000	Incompatible USB version
2	Yamaha DTX 502	Incompatible USB version
3	ATV aD5 Electronic Drums aD5	Incompatible USB version
4	KORG MICROKEY1	