78mm | 78mm | 78mm | 78mm | 78mm | 78mm | 78mm | 78mm | 78mm

正面

BOKE 柏克®

BS-174触摸版 使用说明书

深圳柏克数码科技有限公司
SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD

尊敬的客户:

感谢您使用柏克自主研发的蓝牙音箱,为了让您轻松体验产品,我们配备了向音详尽的使用说明,您从中可以获得有关产品的介绍,使用方法等方面的知识,在您使用本机前请先仔细阅读说明书!

一、外观功能

① 模式选择
② 上选曲/音量减
③ 播放/暂停
④ 下选曲/音量加
⑤ 电源键
⑥ AUX插孔
⑦ US5充电口
⑧ 模式/充电LED



二、使用说明

功能键简要说明	
ON/OFF	电源键
AUX	播放3.5mm音频线输入的声音
MICRO USB	充电接口

1. 功能操作

(1). 电源开关拨到“ON”机器开机,进入蓝牙模式,同时会语音提示,此时蓝牙灯快闪,当配对后常亮,播放歌曲时慢闪亮,电源开关拨到“OFF”位置时,机器关机整机停止工作;

(2). 打开电源开关,机器默认为蓝牙模式,插入3.5立体外音输入插头机器自动切换到“AUX”模式同时伴有语音提示“AUX INPUT MODE”播放外接音源,当拔掉外接3.5立体输入音源线时,机器自动切换到默认的蓝牙模式状态;

(3). 模式切换功能键“M”键:播放音乐时,短按“M”键,可以进行模式切换,切换顺序:“BT-AUX-BT”循环,实现一键转换功能;

(4). 上选曲/音量减功能键“-”键:播放时短按“-”键为上一曲功能,长按“-”(3秒)为音量减小功能;

(5). 下选曲/音量加功能键“+”键:播放时短“+”键为下一曲功能,长按“+”(3秒)为音量增加功能;

(6). 播放/暂停功能键“⏯”播放时短按触摸,第一次短按为暂停播放,重复短按一次切换到播放,机器恢复播放功能;

(7). 电话免提接听功能键“⏯”:当机器在蓝牙播放状态时,来电接听,短按“⏯”键为接听,接听后再短按一次为挂断电话功能,接听前连续两次短按“⏯”为挂断电话,放弃接听;

(8). 在蓝牙播放状态时,长按“M”键(3秒),机器自动进入休睡状态,播放此时停止,重复长按“M”键(3秒),机器自动激活,此功能可以实现一键锁机;

2. 电池充电操作

(1). 拔开音箱背面防尘硅胶塞;
(2). 电池充电器规格要求5V/1A 2A;
(3). 用“MICRO USB”数据线连接手机适配器或电脑USB插座,插入充电线时,充电LED显示为红色,当电池充满电时,红色LED灯熄灭充电完成;

3. 其它功能

(1). 后插优先功能;
(2). 低电量自动提示:低电压自动关机功能;
(3). 蓝牙在5分钟无设备连接时,自动进入假关机模式,如果要唤醒,则长按“M”键3秒才能进入蓝牙模式,在假关机状态下,插“AUX”时能自动激活,当再次要连接蓝牙时,短按M键功能键即转入蓝牙功能;

三、注意事项及特色和功能

(1). 支持AUX功能
(2). 避免放置潮湿地方
(3). 支持蓝牙(无障碍距离≥10米)
(4). 支持蓝牙播音乐,通话
(5). 定期适时充电
(6). 禁用湿布擦拭

四、产品参数

蓝牙方案:	JL V5.0
接收距离:	10M
功率:	5W
阻抗:	4Ω
扬声器尺寸:	50mm
扬声器:	1
频率响应:	80Hz-20KHz
信噪比:	65DB
连接方式:	Bluetooth AUX
外观尺寸:	Φ125*75 mm
电池:	18650 3.7V 2200mA
电源输入:	DC 5V/1000mA
播放时间:	5-6H
充电时间:	3-4H
充电端口:	MICRO USB

五、包装清单

1.BS-174音箱……1个
2.充电线……1条
3.AUX音频线……1条
4.使用说明书……1份

六、常见问题解决方法

现象 / 问题	解决方法
多次连接配对不成功	1、检查音箱是否处于搜索状态,或重新开机。 2、周边蓝牙设备太多,造成搜索困难,关闭其他蓝牙设备。
声音小或失真	1、检测蓝牙设备音量,调节其音量至合适位置。 2、电池电压低请充电。
音乐出现断音	是否超出音箱有效连接距离,或音箱与蓝牙设备有障碍物。
蓝牙状态指示灯不亮	

七、保修说明

1.保修条例:
本产品有效保修期为自出售之日起12个月内,在保修期限内正常使用和维护情况下,非人为损坏,机器本机硬件材料及功能出现问题,无法正常使用,本公司将提供免费维修服务。

2.有偿保修:
(1).超出保修期
(2).不能同时出示购买凭证和保修卡。
(3).错误使用(如超压充电)或擅自拆卸改装。
(4).运输、跌落或自然灾害造成故障及损坏。

3.保修须知:
柏克保留可变更维修方式权利。如果柏克产品不能在所在国进行返修,您可能需要承担运费和手续费。如果您在非原购国寻求维修,您须遵守所有适用的进出口法律法规,并负责所有关税、增值税及其他相关税项和收费。

产品保修卡

产品型号:_____ 顾客姓名:_____
制造编号:_____ 顾客地址:_____
购买日期:_____ 顾客电话:_____
购买商店:_____ E-MAIL:_____
商店电话:_____ 邮 编:_____

请务必认真填写好以上各项资料

深圳柏克数码科技有限公司
地址:深圳市宝安区福海街道塘尾富华工业区第7栋
电话:+86-755-2778 2323
传真:+86-755-2778 2900
免费热线:400-0999-806
邮箱:admin@bokecbf.com
官网:www.bokecbf.com

78mm

背面

BOKE®

BS-174 USER MANUAL

SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD

Please read the instruction manual carefully before using the product

一、Features

① Short press: Bluetooth mode/AUX mode
② Short press: Previous track
Long press: Reduce volume
③ Play/ Pause/ Hands free
④ Short press: Next press
Long press: Raise volume
⑤ ON/OFF button
⑥ AUX Port
⑦ Charging port
⑧ LED



Specifications:

Bluetooth: JL 5.0
Power Output: 5W
Charging Output: 5W/10W QC2.0
Function: Bluetooth, Wireless charging Microphone
Product size: 76.6*76.5*95.5mm
Weight: 265g
Material: ABS+Fabric Build in 2200mAh battery
Frequency Response: 80Hz-20KHz
S/N: ≥80db
Driver Size: Φ50mm

Bluetooth mode

Step 1: Press the power button to the"ON" position for 3s to turn on the unit, the LED will be fast flash in blue, that means the product is waiting for Bluetooth pairing;

Step 2: Turn on the Bluetooth on your device and searching for BS-174, and connect to it once you found (when successfully connect it, the LED will be in solid blue;

Step 3: Playing music in your device;

Step 4: Then you can press the buttons on the; speaker to enjoy the function mentioned above;

If speaker doesn’t connect in 5 minutes, the speaker will enter standby mode long press"M"3s, speaker will back to bluetooth mode again.

Hands-free mode
When there is Bluetooth connection, you can use the speaker to answer your call " ⏯ " Press shortly to pick up any incoming call or short press twice the" ⏯ " to reject any incoming call.

AUX mode
When 3.5mm USB cable connect with the AUX port, the speaker will enter into the AUX mode

Charging mode
Using the USB charging cable offered with one end to the product and one end to any PC USB ports or AC Adaptor(5V only)
Charging supply: 5V/1A 5V/2A

LED Indicators
Turn on: LED fast flash in blue
Bluetooth paired: LED in solid blue
Charging: LED in solid red
Fully charged: LED turns off

Attentions
1. Don’t place thewet places
2. Periodic charge
3. Collison avoidance
4. Don’t wipe with wet cloth

Packing list
1. Bluetooth speaker ----------1
2. Charge cable ----------1
3. Audio cable ----------1
4. User Manual ----------1

Charging mode:

Install in accordance with the manufacturer’s instructions.
Place the speaker in a stable location so they will not fall causing damage to the speaker or cause any bodily harm.
Please ensure reasonable space around the speakers for proper ventilation.
Do not install near any heat sources such as radiators,heat registers,stoves,or other apparatus that produce heat.
Do not place near any form of open flame source, such as lighted candles on the apparatus.
To reduce the risk of fire or electronic shock,do not expose this apparatus to rain or moisture.

Product Warranty Card

Model No: _____ Customer name: _____
Produce No: _____ Customer address: _____
Purchase date: _____ Customer telephone: _____
Purchase shop: _____ E-MAIL: _____
Shop Telephone: _____ Mail code: _____

Pls fill in all the information needed carefully

Shenzhen Bock Digital Technology Co., Ltd
Add:7 Building, Fuhua Industry Zone, Tangwei Fuyong, Baoan Shenzhen, China
TEL:+86-755-2778 2323 FAX:+86-755-2778 2900
E-mail:admin@bokecbf.com
Website:www.bokecbf.com

1.材质:
A.105g双铜 风琴折

***2.工艺:**
A. 双面单色, 正常印刷

***3.制做工艺要求:**
A. 折叠方式:风琴折
B. 按照文件尺寸做, 制作精致, 印刷清晰不掉色, 裁切整齐无残缺, 表面无墨点, 污点等
C. 公差:±0.1mm

4.符合ROHS最新环保要求
带"*"号为QC必检项

BOKE 柏克® 深圳柏克数码科技有限公司 SHENZHEN BOKE DIGITAL TECHNOLOGY CO.,LTD

适用性				产品型号		零件料号			
				零件名称	产品说明书	图纸编号			
				电脑存档					
				绘图		投影方向			
				审核		单位	mm	比例	
NO	变更内容	变更者	日期	核准		页数	1/1	版本	A/0